



10941 Weaver Ave  
So. El Monte, CA 91733

## SE Options for a 2013 Ford SE Type II Van

<u>Itemnumber</u>	<u>Number</u>	<u>Description</u>	<u>SellPrice</u>	
KKK LABELS				
40.	1	Add KKK labels, attach to oxygen compartment and behind drivers seat.	\$0	<input type="checkbox"/>
FUEL				
51.	1	Fuel, fill fuel tank	\$152	<input type="checkbox"/>
PARTITION WINDOW				
A200.	202	Partition window, sliding polycarbonate (clear plexiglass) w/ aluminum edge handles.	\$83	<input type="checkbox"/>
A200.	201	SE Center Console w/ (2) cups holders and map storage under lid.	\$322	<input type="checkbox"/>
A200.	203	Map box with (3) polycarbonate dividers, attaches to rear of center console. (Requires Option #201 Center Console)	\$149	<input type="checkbox"/>
RUBBER MAT				
B300.	301	Rubber mat set (3), rubber mat inserts for (3) ALS shelf areas.	\$75	<input type="checkbox"/>
B300.	302	Royal Blue Upholstery, patient compartment upholstery, fillers, head bumpers and all vinyl including high back seat to be covered in Royal Blue L# 05-007	\$0	<input type="checkbox"/>
B300.	303	Floor Color/Material - Lonseal Lonfloor Flecks Sapphire #502 (Blue) Anti Microbial.	\$0	<input type="checkbox"/>
ADDITIONAL REAR WARNING				
C400.	404	(2) Additional Inboard Rear Warning, (1) Code III 85RLED Red & (1) Code III 85ALED Amber (this requires replacing and relocating (2) scene lights) replace with (2) Code III 41-26 Halogen scene lights w/ 15 degree angled polished aluminum housings, located on upper section of roof. Warning Light layout from drivers side to passenger side as follows: Red-Amber-Red-Amber	\$503	<input type="checkbox"/>
C400.	407	Lightbar All LED, Code III RX2700-58"	\$875	<input type="checkbox"/>
C400.	405	Intersection lights front fenders, (2) Whelen 700 Red Halogen flashing w/ chrome flange.	\$190	<input type="checkbox"/>
C400.	401	LED Warning light package ILOS * (1) Code III RX 2700-58" All LED lightbar * (4) Code III 85R LED upper perimeter lights (2) per side * (2) Code III (1) Red & (1) Amber 85R & 85A LED upper rear perimeter lights	\$1,405	<input type="checkbox"/>
C400.	403	Intersection lights front fenders, (2) Code III 41BZR Red Halogen flashing w/ chrome flange.	\$264	<input type="checkbox"/>
C400.	402	Intersection lights front fenders, (2) Code III 45BZR Red LED w/ chrome flange.	\$316	<input type="checkbox"/>
C400.	406	Headlight flasher w/ Lit White rocker switch located in overhead console.	\$201	<input type="checkbox"/>

# SE Options for a 2013 Ford SE Type II Van

<u>Itemnumber</u>	<u>Number</u>	<u>Description</u>	<u>SellPrice</u>	
HANDHELD SPOTLIGHT				
D500.	501	100,000 CP Handheld Spotlight, black rubber, halogen, hard wired, (mounting clip supplied loose)	\$117	<input type="checkbox"/>
110V OUTLET				
E600.	607	Electrical outlet 120V, additional location, (show on print), pilot light, stainless plate, tie into 120V circuit. (in addition to standard)	\$98	<input type="checkbox"/>
E600.	604	Power Inverter and Battery Charger, Vanner "LifeStar" 20-1050 CUL-DC, with fully integrated 1FM1 module, and Leader supplied rocker switch.	\$1,264	<input type="checkbox"/>
E600.	603	Dome lights ILOS, (5) Whelen 9 Diode LED White.	\$584	<input type="checkbox"/>
E600.	608	Electrical outlet 12V, cigarette style. (in addition to standard)	\$50	<input type="checkbox"/>
E600.	601	Power inverter and battery charger - Xantrex, Freedom, HW-1000W, w/ auto transfer, (connected to electrical outlets and shoreline).	\$948	<input type="checkbox"/>
E600.	602	Dome lights ILOS, (5) Whelen 6 Diode LED White.	\$301	<input type="checkbox"/>
E600.	605	Battery charger, IOTA 45 amp. (connected to shoreline)	\$262	<input type="checkbox"/>
E600.	606	Battery charger, IOTA 75 amp. (connected to shoreline)	\$349	<input type="checkbox"/>
ROAD SAFETY				
F700.	706	Pre - Wire for Road Safety System. Includes wire harness, Receiver with speaker, Vehicle antenna and Spotter Switch Kit (NO Connection made).	\$514	<input type="checkbox"/>
F700.	703	Hidden Door Lock Switch (grille area) NOTE: Installation of Remote Door Lock Switch feature may increase the likelihood of unauthorized entry into vehicle. By checking this option, purchaser further agrees to hold Leader Ind. or chassis manufacture harmless for any loss of vehicle or contents caused by unlawful access.	\$92	<input type="checkbox"/>
F700.	702	("SE" GAS CHASSIS) Emergency Start TRI System. (One additional battery located under vehicle, mounted on curb side OEM frame rail)	\$823	<input type="checkbox"/>
F700.	704	Air Conditioning Auxiliary Condensor, Dual fans, located under vehicle. (Not Leader Approved) Manufacture warranty only.	\$1,107	<input type="checkbox"/>
F700.	707	12 Volt High Flow Water Pump, improves water flow to patient compartment heater.	\$241	<input type="checkbox"/>
F700.	705	MBO Antenna Base (each)	\$43	<input type="checkbox"/>
F700.	701	("SE" DIESEL CHASSIS) Emergency Start QUAD battery System. ( Two additional batteries located under vehicle, mounted on OEM frame rail at rear). NOTE: With this option you can not add a auxiliary A/C condensor.	\$1,148	<input type="checkbox"/>
OXYGEN SMALL BOTTLE HOLDER				
G800.	806	Oxygen small bottle holder, Ferno #516, floor mount dual, (ship loose only).	\$125	<input type="checkbox"/>
G800.	805	Oxygen small bottle holder, Ferno #515, floor mount single, (ship loose only).	\$71	<input type="checkbox"/>

# SE Options for a 2013 Ford SE Type II Van

<u>Itemnumber</u>	<u>Number</u>	<u>Description</u>	<u>SellPrice</u>	
G800.	810	Oxygen wrench, cable to wall by large bottle.	\$28	<input type="checkbox"/>
G800.	809	Oxygen small bottle holder, Ferno #521, single bottle, wall mount, safety style	\$221	<input type="checkbox"/>
G800.	807	Oxygen small bottle holder, Ferno #519, wall mount single, (ship loose only).	\$100	<input type="checkbox"/>
G800.	804	Oxygen regulator, preset 50 psi.	\$82	<input type="checkbox"/>
G800.	808	Oxygen small bottle holder, Ferno #520, dual wall mount, (ship loose only).	\$100	<input type="checkbox"/>
G800.	811	Aspirator portable, SSCOR Model #2310BV-S-CORT	\$854	<input type="checkbox"/>
G800.	802	Flowmeter Integrated, Amvex 0-15 LPM (Tube Style) Replace (1) Standard Oxygen Faceplate	\$198	<input type="checkbox"/>
G800.	801	Flow meter, 0-15 LPM, Ohio disconnect.	\$66	<input type="checkbox"/>
G800.	813	Quantity (2)	\$489	<input type="checkbox"/>
G800.	815	Air regulator, preset to 50 psi.	\$115	<input type="checkbox"/>
G800.	814	Air outlet, action area, Ohio style quick release, plumbed to remote bottle. Includes additional "M" size bottle rack located on top of oxygen rack.	\$473	<input type="checkbox"/>
G800.	813	Quantity (1)	\$245	<input type="checkbox"/>
G800.	813	Oxygen small bottle holder quick release, ZICO #QR-E-1, single "E" bottle only (strapless)	\$0	<input type="checkbox"/>
G800.	809	Quantity (2)	\$443	<input type="checkbox"/>
G800.	809	Quantity (1)	\$221	<input type="checkbox"/>
G800.	803	Flow meter Dial Preset, 0-25 LPM, Ohio disconnect.	\$116	<input type="checkbox"/>
G800.	812	Quantity (2)	\$489	<input type="checkbox"/>
G800.	812	Quantity (1)	\$245	<input type="checkbox"/>
G800.	812	Oxygen small bottle holder quick release, ZICO #QR-D-2, single "D" bottle only (strapless)	\$0	<input type="checkbox"/>
DOOR HOD OPEN SIDE DOOR				
H900.	907	Door hold open, patient compartment side door, Cast Product grabber with heavy duty polished aluminum re-enforcement bracket.	\$121	<input type="checkbox"/>
H900.	904	Net, Font End of Squad Bench. (1) Leader style, (5) Ancra fasteners, (1) ratchet buckle, and Black 1 1/2" webbing.	\$314	<input type="checkbox"/>
H900.	905	Fire Extinguisher,ABC,5 Lb. Loose	\$51	<input type="checkbox"/>

# SE Options for a 2013 Ford SE Type II Van

Itemnumber	Number	Description	SellPrice	
H900.	906	6" Yellow strap w/ the word "CAUTION" stenciled in Red. Locate insde above rear doors.	\$62	<input type="checkbox"/>
H900.	902	(FORD) Front License Plate Step	\$112	<input type="checkbox"/>
H900.	903	(FORD) Bumper Guards, Front , Chrome, with black insert.	\$146	<input type="checkbox"/>
H900.	901	(FORD) - Convex "Blind Spot" Mirror, (2) Driver and Passenger Mirrors.	\$81	<input type="checkbox"/>
COT				
I1000.	1001	Cot, Ferno #35A multi-level, #460 bolster mattress, maroon, #417-1 harness, maroon, (2) #430 restraints, maroon, for #175 fastener.	\$2,898	<input type="checkbox"/>
I1000.	1011	Defibrillator platform Stryker MX PRO	\$323	<input type="checkbox"/>
I1000.	1008	Cot, Stryker POWER-PRO XT #6506, (1) SMRT Charger, (2) SMRT PAKS and (1) Selected Power Cord 12V or 120V, G Rated Bolster Mattress, G Rated Restraint Paackage. (Options listed below are for Stryker MX PRO cot only)	\$12,985	<input type="checkbox"/>
I1000.	1010	Additional wheel brake Stryker cot	\$102	<input type="checkbox"/>
I1000.	1019	Base storage tray MX PRO	\$130	<input type="checkbox"/>
I1000.	1018	Base storage net MX PRO	\$160	<input type="checkbox"/>
I1000.	1017	Permanent oxygen holder MX Pro ( foot end )	\$132	<input type="checkbox"/>
I1000.	1015	IV pole 2-stage Pt right MX PRO	\$261	<input type="checkbox"/>
I1000.	1014	Head end pouch vinyl MX PRO	\$170	<input type="checkbox"/>
I1000.	1020	Cot Safety Hook at Rear Sill w /Reflective tape	\$66	<input type="checkbox"/>
I1000.	1012	IV pole 3- stage Pt right MX PRO	\$247	<input type="checkbox"/>
I1000.	1002	Cot, Ferno #93-ES, 3-level, #460 bolster mattress, maroon, #417-1 harness, maroon, (2) #430 restraints, maroon, for #175 fastener.	\$3,598	<input type="checkbox"/>
I1000.	1009	Stryker stair pro Chair 6252	\$3,075	<input type="checkbox"/>
I1000.	1005	Cot, Stryker, MX-Pro #6082 R3, Std Rugged, mattress, black, restraints, black.	\$4,483	<input type="checkbox"/>
I1000.	1006	Ferno Fastener #1, ship loose.	\$321	<input type="checkbox"/>
I1000.	1007	For Ferno #35-A cot	\$446	<input type="checkbox"/>
I1000.	1007	For Ferno #93ES cot	\$446	<input type="checkbox"/>
I1000.	1007	Cot fastener, Ferno #175-5, wall mount, rear hook, removable antlers, (for Ferno cot only). (Specify Cot Model)	\$0	<input type="checkbox"/>

# SE Options for a 2013 Ford SE Type II Van

<u>Itemnumber</u>	<u>Number</u>	<u>Description</u>	<u>SellPrice</u>	
I1000.	1004	Cot fastener, Ferno #173-2, permanent mount, for #28 cot only).	\$352	<input type="checkbox"/>
I1000.	1003	Cot, Ferno #28 stair chair/cot, roll-in, mattress, maroon, #417-1 harness, maroon, (2) #430 restraints, maroon, ( requires 5 inch PVC spacer on lower portion of streetside cabinet).	\$2,962	<input type="checkbox"/>
I1000.	1013	Ergonomic package MX PRO	\$171	<input type="checkbox"/>
WINDOW TINT				
J1100.	1101	Add window tint to patient compartment OEM windows.	\$161	<input type="checkbox"/>